

Pneumatic Sanding Set Maintenance Guide

Symptoms	Causation	Trouble shooting
Motor does not work	No power supply	Check the socket, the power cord and power supply
	Wrong setting of the switch	Open the motor switch
Motor abnormalities	Current overload	Check the voltage and current
	Long-term no replacement of carbon stick	Replace the carbon stick
	Lack of phase	Check the power line
	Circuit board burned	Replace the circuit board
Weak Suction Effect	Filter bag is full (disposable filter bag)	Replace the filter bag
	Air filter clogged	Replace the air filter
	Pipe or rotate adapter clogged	Cleanup the blockage
	Pipe broken	Replace the pipe
	Sealing rubber damaged	Replace the sealing rubber
	Dust chamber damaged	Replace the dust chamber
Dust overflow during the dust extractor working	Wrong installation of air filter	Check the air filter installation
	Air filter damaged	Replace the air filter